(03050106-020)B-086 Sharon Biomonitoring Stations Water Quality Monitoring Sites NPDES Permits Surface Water Intakes Mines Landfills Highways Modeled Streams Streams County Lines 11-Digit Hydrological Units McConnells City Lakes 0177-91 0759-91 SC0043095 SCG72000 Public Lands 0180-23 Lowrys IWP-209 B-136 Turkey Sumter National Forest

**Turkey Creek Watershed**